


**PGM Volume should always be between -9db and 0db**

**DO NOT TOUCH**



Use Monitor master volume to adjust loudness of the Monitor speakers

**White buttons** should be selected on all channels for Mics & Players

Push **grey button** to send phone to this channel

Use Phones master volume to adjust loudness of the headphones